


ALPConnect™ Bluetooth module for AL Priority®

This optional module enables wireless connection to your AL Priority® with your iPhone™ or iPod™

ALPConnect BT Module comes with a C to C connection cable.

Use this cable to connect the Bluetooth module with the C socket of your AL Priority Control Box.



Read instructions in your AL Priority Manual when installing remaining parts of the AL Priority system.

IMPORTANT NOTICE: If you intend to mount the whole system including AL Priority Control Box with the BlueTooth module inside the engine compartment, you must use adequate plastic waterproof enclosure to protect the AL Priority Control Box and the BlueTooth Module from moisture. If these parts of the system get exposed to water it is likely to cause damage or malfunction that is not warranty covered.

1. Once your AL Priority system with the BT Module is installed, search iTunes for ALPConnect.
2. Download it and install it to your iPhone (4s or later). ALPConnect will also work on iPad 3 and later, iPod Touch 5 and iPad mini.
3. Once you start the ALPConnect you must SCAN for BlueTooth devices and connect to your AL Priority with the Serial Number and PIN (both numbers are labeled on the BlueTooth Module).

Detailed instructions about the ALPConnect application can be found on our website.

All intellectual rights in this product, including software are proprietary.
Radikal d.o.o. Croatia © November 2013
Visit us at www.alpriority.com
Contact us at info@alpriority.com